



A PUBLIC SAFETY EQUIPMENT COMPANY

www.code3pse.com • 314-426-2700

# Mounting Kit Adapters Cross Reference Guide

CARS, SUVs, TRUCKS, AND VANS			
MAKE/MODEL	YEAR	HOOK KIT MODEL #	ROOF WIDTH
<b>CHEVROLET/GM</b>			
Avalanche	2002-12		55.0"
Camaro	2011-12		50.0"
Canyon	2004-12	GMBTRK	45.5"
Caprice	2011-12	CVYCPR11	49.25"
Colorado	2004-12	GMBTRK	45.0"
Cruze	2012		46.5"
Equinox (w/ roof rack)	2005-12	CVYEQ	48.5"
Express Van	2003-12		61.0"
HHR	2007	FCV360	
Impala	2006-11	CVYIMP06	46.5"
	2000-05	CVYIMP	51.0"
Malibu	2012		48.0"
	2008-11		47.0"
	2004-07	CVYMAL	44.0"
Silverado	2007-12	CVYTH07	55.0"
	1998-06	GMBTRK	52.0"
Suburban	2007-12	CVYTH07	55.0"
	1992-06	GMBTRK	52.0"
Tahoe	2007-12	CVYTH07	55.0"
	1995-06	GMBTRK	52.0"
Trail Blazer/Envoy	2002-10	GMBTRK	51.0"
Traverse	2012		53.0"
	2010	CVYTRV	
Uplander	2007-08	HKB-UPL7	50.0"
	2005-06	FDXPLR	
Volt	2012		47.50"
<b>CHRYSLER/DODGE/JEEP</b>			
200	2012		50.0"
Challenger	2012		54.5"
Charger	2011-12	DGCHR11	50.25"
	2006-10	DGCHR	47.0"
Commander	2010		56.0"
Dakota	1998-12	FDXPLR	45.5"
Durango	2011-12		54.0"
	2007-09	DGDUR07	48.0"
	2001-06	FDCV92	46.0"
Grand Caravan/Town & Country	2008-12		60.0"
	1996-07		48.5"
Grand Cherokee	2011		54.0"
	2005-09	ASTRVN	
Laredo	2002-2007		50.0"
Liberty	2012		55.0"
	2002-05	JEEPLIB	46.0"
Magnum	2005-08	HKBLAZ	
Nitro	2007-10	DGNIT07	
Patriot	2010	JEEPPAT	
Ram	2010-12		57.5"
	2003-09	GMBTRK	48.5"
Rubicon	2006-08	JEEP RUB	
Wrangler	2006-08	JEEP RUB	

CARS, SUVs, TRUCKS, AND VANS			
MAKE/MODEL	YEAR	HOOK KIT MODEL #	ROOF WIDTH
<b>FORD</b>			
Crown Victoria	1992-11	FDCV92	46.0"
Edge	2012		52.0"
Escape	2008-12	TOYPRIUS	49.5"
	2005-07	CVYMAL	49.0"
	2001-04		49.0"
Excursion	2000-06	ASTRVN	57.0"
Expedition	1998-12	HKBLAZ	52.0"
Explorer	2011-12	CVYEQ	55.0"
(2011-12 w/ roof rack)	2007-10	HKBLAZ	51.0"
	2000-06	FDCV92	49.0"
Explorer Sport Trac	2008-09	HKBLAZ	
F150	2009-10	CVYIMP06	57.0"
	2004-08	FD150PU	57.0"
	1997-03	FD150PU	52.0"
F250/350/450/550	2010-11	ASTRVN	58.5"
	2008-09	FDXPLR	58.5"
	1998-07	ASTRVN	58.5"
F650/750	2010-12	FD650PU	
Five Hundred	2007	FD507	
Flex	2012		57.0"
	2009	FDCONVN	
Focus	2008-12	DGCHR	48.0"
Freestar Minivan	2005	FDCV92	
Freestyle	2007	FDFREE	
Fusion	2006-12	HKBLAZ	48.5"
Mustang	2001-2012	HKBLAZ	46.0"
Police Interceptor Sedan	2012	CVYIMP06	52.5"
Police Interceptor Utility	2012	FDXPLR11	55.0"
Ranger	1995-10	GMBTRK	48.5"
Taurus	2011-12	CVYIMP06	52.5"
	2009		49.0"
	1996-07	HKBLAZ	
Transit-Connect Van	2010-12	FDCONVN	
E Series Van	1987-12	GUTTERHK	65.0"
<b>GMC</b>			
C5500/6500/7500/8500	2009-10	GUTTERHK	
Canyon	2004-12	GMBTRK	45.5"
Envoy	2002-07		49.5"
Sierra	2007-12	CVYTH07	55.0"
	1998-06	GMBTRK	52.0"
Yukon	2007-12	CVYTH07	55.0"
	1995-06	GMBTRK	52.0"
<b>HONDA</b>			
Civic	2001-09	HNCVC	
CRV	2006-08	CVYIMP06	
<b>ISUZU</b>			
DMAX	2007	IZDMAX	
<b>MERCEDES-BENZ</b>			
E Series	2006	FD150PU	
<b>PONTIAC</b>			
Vibe	2008-09	PVIBE	



A PUBLIC SAFETY EQUIPMENT COMPANY

www.code3pse.com • 314-426-2700

# Mounting Kit Adapters Cross Reference Guide

CARS, SUVs, TRUCKS, AND VANS			
MAKE/MODEL	YEAR	HOOK KIT MODEL #	ROOF WIDTH
<b>TOYOTA</b>			
Commuter Van	2007	TOYVAN	
Corolla	2006-10	DGCHR	
Highlander	2006-07	CVYMAL	
	2008	TOYHIGH08	
PreRunner	2007-08	TOYTAC	
Prius	2006-09	TOYPRIUS	
Rav 4 (w/ roof rack)	2008-09	CVYEQ	
Tacoma	2007-08	TOYTAC	
Tundra	2007-09	HNCVC	
Vigo	2006-08	TOYPRIUS	



Measurement of Vehicles with Wrap-Around Doors



Measurement of Vehicles with Standard Roof.