

Front Pod Blue/Red/ Warning Lights Amber/White Takedown/Alley Lights White **Rear Pod** Warning Lights Blue/Red/ Amber/White Stop/Tail Red Turn Signals Amber ID Lights Red/Blue Saddle Bag Lights White Rear Pod Central Controller

Front Pod Warning Lights

Blue/Red/ Amber/White

Flasher

Rear Pod Warning Lights

Blue/Red/ Amber/White

Flasher

To obtain Code 3 equipment contact your nearest authorized BMW Motorcycle Retailer or call (800) 345-4BMW for the location of the retailer nearest you. You may also e-mail BMW Motorrad USA, Authority Sales at Frank.Stevens@ bmwna.com, or visit their police web site at www.bmwmc.net.