

Z3 Siren Configuration Software Requirements

The Z3 Siren Configuration Software requires the following items to function properly:

- PC or laptop computer with a USB port and a CD-ROM drive.
- Microsoft Windows™ XP Service Pack 3, Windows Vista (32 Bit & 64 Bit) or Windows 7 (32 Bit & 64 Bit).



- USB cable (A Male to A Male).
- PDF reader to open the four PDF files available on the CD. These include this manual along with the Installation & Operation Manual, Hardware Quick Install Manual and Software Quick Setup Manual. The two full manuals are also available through the help drop-down menu of the software

Software Installation on Windows XP

1. Insert the software installation CD into the CD-ROM drive.
2. If the software automatically starts the install process, skip to step 6. Otherwise go to the next step.
3. From the Windows Start button, select Run, then click on Browse and navigate to your CD-ROM drive.
4. Select the Setup.exe file and press Open.
5. Press OK to run Setup.exe which will start the setup.
6. Follow the instructions presented by the installation wizard.

After the software installation is complete, the program is started by double-clicking on the **Z** icon created on the desktop. The user can then configure and assign features and functions to each of the push-buttons, slide-switch positions, auxiliary inputs, etc. After clicking on the appropriate control, the settings that are available for that control are displayed. The setup can be saved for future use.

NOTE: Power must be connected to the two pin connector labeled with +12VDC and GND at the lower right of the Z3 Siren. If the Ignition input is connected to +12VDC during configuration, the Z3 Control Head will be disabled. The Control Head will begin to blink and beep to indicate that it is disabled. Configuration can be completed and the Z3 Siren will automatically restart when the USB cable is disconnected. No other connections are required, but will not interfere with configuration if connected.

Software Installation on Windows 7 and Vista

1. Insert the software installation CD into the CD-ROM drive.
2. If AutoPlay window pops up, select “Run setup.exe” and go to step 6. Otherwise continue to step 3.
3. From the Start button, select Run, then click on Browse and navigate to your CD-ROM drive.
4. Select the Setup.exe file and press Open.
5. Press OK to run Setup.exe which will start the setup.
6. Follow the instructions presented by the installation wizard.

After the software installation is complete, the program is started by double-clicking on the **Z** icon created on the desktop. The user can then configure and assign features and functions to each of the push-buttons, slide-switch positions, auxiliary inputs, etc. After clicking on the appropriate control, the settings that are available for that control are displayed. The setup can be saved for future use.

NOTE: Power must be connected to the two pin connector labeled with +12VDC and GND at the lower right of the Z3 Siren. If the Ignition input is connected to +12VDC during configuration, the Z3 Control Head will be disabled. The Control Head will begin to blink and beep to indicate that it is disabled. Configuration can be completed and the Z3 Siren will automatically restart when the USB cable is disconnected. No other connections are required, but will not interfere with configuration if connected.

Installation of USB Driver For Z3 Siren

If this is the first time a Z3 Siren has been connected to this computer, a Windows Security screen will pop up. Allow the drivers to be installed. Future Z3 Sirens will connect automatically as long as the same USB port is used (see the Configuration Software User Manual for details).

Basic Steps to Configure the Z3 Siren

1. Launch the Z3 Siren Configuration software.
2. Connect PC to the USB cable.
3. Connect the USB cable to the Z3 Siren.
4. Connect power to the Z3 Siren.
5. Configure the Z3 Siren in the software as desired.
6. Export the configuration to the Z3 Siren.
7. Remove USB cable from the Z3 Siren.
8. Remove power from the Z3 Siren.
9. Repeat steps 3-8 for additional Z3 Sirens.
10. Save configuration.

Code 3, Inc.
10986 N. Warson Road
St. Louis, Missouri 63114-2029—USA
Ph. (314) 426-2700 Fax (314) 426-1337
www.code3pse.com

Code 3,® Inc., a subsidiary of
Public Safety Equipment, Inc.