

INSTALLATION GUIDE

XT4 Side View Mirror Mounting Brackets



Installing the XT4 Side View Mirror Lights:

Step-1. Position the supplied mounting bracket as desired on the vehicles plastic mirror housing to determine the desired mounting angle and location.

Step-2. Use the mounting bracket as a template to locate and drill holes in the vehicles plastic mirror housing for the wires and start holes for the mounting screws. **Caution: It is advisable to remove the mirror from the housing to be sure the locations of the drilled holes will not damage the OEM components inside the housing!**

a. Drill the start holes for the mounting screws with a 3/32" .0937" diameter drill and drill the wire hole with a 3/8" .375 diameter drill.

Step-3. Install the light head.

a. Hold the smaller gasket against the vehicles plastic mirror housing (This gasket fits just inside the bracket and its purpose is to hide the wires behind the mounting bracket after the unit is tightened up against the vehicles mirror housing).

b. Hold the mounting bracket in position against the vehicles plastic mirror housing.

c. Hold the light head gasket in position against the mounting bracket.

d. Feed the light head wires in through the 3/8" hole and into the vehicles plastic mirror housing making sure they will be accessible from inside the housing to complete the wiring.

e. Hold the light head in position over the assembly.

f. Thread the (2) supplied #6 X 1 1/2" long Stainless Steel Phillips Pan Head Sheet Metal Screws through everything and into the start holes in the vehicles plastic mirror housing.

Step-4. Tighten each of the screws a little at a time until they are just tight enough to snug the assembly up against the vehicles plastic mirror housing. Be careful **"DO NOT TO OVER TIGHTEN THE SCREWS"** as that could potentially strip out the plastic around the screws.

Step-5. In the final assembly the mounting bracket is sandwiched between the light head and the vehicles plastic mirror housing.

Step-6. Complete the wiring as desired! **Note: If this is a component included in a CELS Package, see the CELS-CC Housing Instruction Manual for the remaining wiring connections.**

NEED HELP? Call our Technical Assistance HOTLINE - (314) 996-2800



DO NOT APPLY 12 VOLTS DIRECTLY TO THE XT4 LIGHT HEAD WIRES AFTER THE LIGHT HEAD IS CONNECTED TO THE CELS CC BOX. IF THE XT4 IS A COMPONENT OF THE CELS SYSTEM THE CC BOARD OR THE LIGHT HEADS COULD BE DAMAGED BY APPLYING 12 VOLTS TO THE CC OUTPUTS!