

INSTALLING THE POWER QUICK DISCONNECT



Determine a convenient location to install the quick disconnect, and cut the 8ga wire. Strip about 1/2" of insulation from each end (3/4" if soldering). Slide on the adapter sleeve. Be careful to keep all strands inside the sleeve.



Slide the contact over the sleeve as shown.



Crimp the contact securely. Pull on the contact to assure a tight crimp. If soldering, make sure solder flows into the sleeve and contact, as well as up the 1/4" of exposed wire.



Slide the contact into the housing as shown, with the notch down. This will engage the metal retaining tab and secure the contact. The "bump" should be up as in the photo.



Repeat for other end of the wire and slide the 2 connectors together

To remove a contact from its housing, use a small flat blade screwdriver to press down on either side of metal retaining tab under the contact. This will allow the wire and contact to be pulled out of the housing.

PROBLEMS OR QUESTIONS? CALL OUR TECHNICAL ASSISTANCE HOTLINE (314) 996-2800

WWW.CODE3PSE.COM

Code 3,® Inc., a subsidiary of
Public Safety Equipment, Inc.

CODE 3
PUBLIC SAFETY EQUIPMENT, INC.

Code 3®, Inc.
10986 N. Warson Road
St. Louis, Missouri 63114-2029—USA
Ph. (314) 426-2700 Fax (314) 426-1337

Code 3® is a registered trademark of Code 3, Inc., a subsidiary of Public Safety Equipment, Inc.

Part No. T07295 Rev. 1 5/2006
©2005 Code 3, Inc